

HCFC, R-22, Mid Point, 60 Hz, 3 - Phase, 208/230 V

Air Conditioning

Production Status: This model is obsolete and is no longer in production for both OEM and service replacement.

Service Parts

<u>Reference</u>	<u>Component</u>	<u>Quantity</u>	<u>Description</u>	<u>Comments</u>
	020-0635-00	1	GASKET-DEEP SUMP	
1	002-0160-00	2	HEAD-CYLINDER	2866062
2	002-0192-01	2	HEAD-CYL UNLOADER	
3	020-0600-00	2	GASKET-CYLINDER HEAD	2866119
4	020-0616-00	2	GASKET-CY HEAD UNLOADER	2871502
6	998-0008-33	1	OIL PUMP KIT	WITH OIL PUMPBOLTSGASKETS& ADAPTER RINGS
7	918-0518-00	1	CRANKCASE HTR KIT 120V	120 VOLT200 WATTINSERTION
7	918-0518-01	1	CRANKCASE HTR 240V	240 VOLT200 WATTINSERTION
8	998-0510-07	1	SERV VALVE KIT 1 5/8 SWT	DISCHARGE
9	020-0006-46	1	GASKET-CIRCULAR	DISCHARGE
10	998-0510-18	1	SERV VALVE KIT 3 1/8 SWT	SUCTION
11	020-0006-58	1	GASKET-CIRCULAR	SUCTION
12	998-5100-31	1	SUCT & DISCH VALVE KIT	WITH VALVESBOLTS& GASKETS
13	005-0563-00	1	COVER-STATOR	2917391
14	020-0597-00	1	GASKET-STATOR COVER	2917528
15	998-0002-02	1	SIGHT GLASS KIT	
16	527-0115-00	1	SPACER-MOUNTING GROUP	
17	020-0853-01	1	GASKET-VALVEPLATE	
17	998-1661-31	2	VALVE PLATE KIT-STD LOAD	
18	998-1661-32	2	VALVE PLATE KIT-UNLOADED	
19	020-0664-04	3	GASKET-VALVE PLATE	2866142
20	020-0636-00	1	GASKET-HOUSING COVER	
21	020-0733-00	1	GASKET-OIL PUMP	
23	998-0212-02	1	UNLOADER VALVE/COIL 120V	
24	020-0931-00	2	GASKET-UNLOADER SHIPPING	
25	504-0230-00	1	PISTON-UNLOADER ASSM	
26	998-0524-10	1	SOLID STATE MODULE KIT	
27	020-0638-00	1	GASKET-TERM PLATE	
28	062-0208-00	1	BOX-TERMINAL	
29	580-0054-00	1	BOARD-PILOT TERM ASSM	3060254
30	521-0142-02	1	TERMINAL-PLATE GROUP	
31	005-0430-00	1	COVER-TERMINAL BOX	2864613
32	521-0065-03	1	TERMINAL-PARTS GROUP	
33	548-1051-00	1	SHELL-STRAINER ASSM	2917471
34	998-0513-02	1	OIL SCREEN KIT	
35	998-0335-00	1	SERV CHECK VALVE KIT	
36	998-0051-00	1	PRES RELIEF VALVE KIT	

seth, jeffrey.
10/10/2007

<u>Reference</u>	<u>Component</u>	<u>Quantity</u>	<u>Description</u>	<u>Comments</u>
37	998-1669-05	1	GASKET SET	
38	510-0257-00	1	VALVE-OIL CHECK ASSM	
39	503-0430-00	1	PLATE-OIL SUMP ASSM	
40	006-0200-00	1	SPRING-UNLOADER	
41	998-0212-03	1	UNLOADER VALVE/COIL 240V	
42	528-1573-00	1	TUBE-SNORKEL ASSIST	AUGMENTOR TUBE
44	998-0700-11	1	OIL CONTROL BRACKET KIT	
45	020-0297-13	1	GASKET-SENTRONIC SENSOR	
46	020-0844-04	1	SEAL-SIGHT GLASS	2042028